



INSTALLATION INSTRUCTION

Handles


OH45-275E1



OH45-275E1




OH45-275E1




1

OH_45...275_E011

OH_45...275_E421



2




3

OH45-275E1

Ø5...10 mm
Ø0.20...0.39 in



OH_45...275_E311





OH_45...275_E011

OH_45...275_E311


OH_45...275_E421



OH45-275E1



OH45-275E1



A	L	□
OH B 45J5E_	45	5
OH B 45J6E_	45	6
OH B 45J10E_	45	10
OH B 65J5E_	65	5
OH B 65J6E_	65	6
OH B 65J8E_	65	8
OH B 65J10E_	65	10
OH B 80J6E_	80	6
OH B 80J8E_	80	8
OH B 80J10E_	80	10
OH B 95J10E_	95	10
OH B 95J12E_	95	12
OH B 125J10E_	125	10
OH B 125J12E_	125	12
OH B 145J12E_	145	12
OH B 175J12E_	175	12
OH B 275J12E_	275	12

J = IP65, UL/NEMA Type 1, 3R, 12
H = IP54, L = UL/NEMA Type 4, 4X

B = ■ Y = ■ G = ■



Contact us

ABB Oy

P.O. Box 622
FI-65101 Vaasa
Finland

abb.com/lowvoltage